

Setback Distances in feet
 Traverse County, Minnesota Table date: February 3, 2012

Map Unit Symbol	Drain Depth, feet			
	2	3	4	5
26	50	50	60	70
34	60	80	100	120
46	100	160	210	260
47	60	90	110	130
51	60	80	100	120
56	50	70	90	100
57	50	60	70	90
58	60	90	110	130
60	70	110	150	180
108	50	70	90	110
184	50	70	90	110
236	50	70	90	100
276	50	70	90	100
293	70	100	120	130
343	130	200	220	240
344	60	80	100	110
371	100	170	230	280
418	60	90	120	140
434	50	60	80	100
450	70	100	130	160
582	50	70	90	110
642	60	90	110	130
698	50	50	60	70
814	50	70	90	110
816	50	70	90	100
821	50	50	60	70
900	50	70	90	110
922	50	70	90	110
948	50	70	90	110
1916	50	80	100	120
1918	140	160	180	200
1933	60	90	110	130
1940	60	80	100	110
1947	50	80	120	150
1948	50	70	90	100

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
 Traverse County, Minnesota Table date: February 3, 2012

1949	80	120	160	190
1950	50	70	90	100
171B	50	50	60	70
245B	140	220	290	360
494B	50	70	90	100
646B	50	60	70	80
67A	60	90	110	130
67B	60	90	110	130
822B	50	60	70	80
915B	50	50	60	70

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.