

Setback Distances in feet  
 Redwood County, Minnesota      Table date: March 8, 2012

Map Unit Symbol	Drain Depth, feet			
	2	3	4	5
86	50	60	70	90
227	120	200	270	350
247	140	220	290	320
255	130	230	310	370
282	120	220	320	380
313	50	50	70	80
317	60	90	110	130
392	120	250	350	400
399	130	250	350	400
423	50	60	80	100
562	50	60	80	90
574	50	60	70	90
575	50	70	80	100
654	50	60	80	90
818	110	170	220	270
884	50	60	80	100
1833	50	50	60	80
1834	50	50	60	80
1850	50	60	70	80
1897	50	70	80	100
1024A	50	50	60	70
1056A	50	90	110	140
128A	80	120	150	180
128B	80	120	150	180
1851B	70	100	120	140
1899B	50	60	80	90
27A	90	150	200	260
27B	90	150	200	260
327A	120	210	280	340
327B	110	200	270	340
39A	170	310	400	400
39B	170	310	400	400
41A	140	230	300	380
41B	140	230	300	380
421B	50	70	90	100

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet  
 Redwood County, Minnesota      Table date: March 8, 2012

421B2	50	70	90	110
42C	220	350	400	400
94B	50	60	80	90
954B2	50	70	90	110
999B2	50	70	90	110
L141A	50	50	70	80
L142A	50	50	60	80
L149A	50	60	80	90
L163A	50	60	80	100
L173A	50	50	70	80
L198A	50	50	60	70
L198B	50	50	60	70
L201A	50	70	90	110
L202A	50	50	70	80
L214A	60	80	110	130
L219A	50	50	60	70
L221A	50	60	70	90
L224A	50	50	60	70
L225B	50	50	70	80
L229A	50	60	80	90
L242B	50	70	80	100
L243A	50	50	60	70
L244A	50	60	70	90
L247A	50	50	70	80
L248B	50	50	70	80
L252A	130	240	330	400
L253B	90	150	200	260
L83A	50	60	80	90
L84A	50	60	70	90

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.