

Setback Distances in feet
 Pope County, Minnesota Table date: March 8, 2012

Map Unit Symbol	Drain Depth, feet			
	2	3	4	5
Af	70	130	170	220
As	80	130	160	200
BaA	50	60	70	90
BbB2	50	60	70	90
BdB2	50	60	70	90
BdB2	50	60	70	90
Be	50	70	90	100
Bh	90	130	150	180
Ca	50	60	70	90
CmB	50	70	80	100
Cn	100	160	220	270
Co	50	70	90	110
Cp	50	70	90	110
DaB	50	70	80	100
DcA	100	170	230	280
DcB	100	170	230	280
DIA	50	60	80	90
DIB	50	60	80	90
Es	140	250	340	400
Et	180	340	400	400
EvA	180	290	390	400
EvB	180	290	390	400
EwA	190	330	400	400
EwB	190	330	400	400
FIA	100	150	200	240
FIB	100	150	200	240
FoA	120	210	280	350
FoB	120	210	280	350
FrB2	50	70	80	100
Gn	50	60	70	90
Hc	140	220	290	360
Hd	50	70	90	110
Hv	130	210	280	350
Lc	70	130	170	220
Lh	70	130	170	220

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
 Pope County, Minnesota Table date: March 8, 2012

	Li	50	60	70	90
Lk	70	130	170	220	
Lk	80	140	180	230	
LnB2	50	50	70	80	
LnB2	50	60	70	90	
Lo	50	60	70	90	
Ma	50	70	80	90	
MdA	120	190	250	310	
MdB	120	190	250	310	
Mf	110	190	250	320	
MI	170	290	390	400	
Mn	110	190	260	330	
Mo	110	190	270	350	
Mr	130	210	280	350	
Ms	50	70	90	110	
Mt	70	120	150	190	
Mu	70	120	150	190	
Mv	70	120	150	190	
Mw	60	80	110	130	
Mx	170	290	390	400	
My	60	80	110	130	
Mz	120	230	310	400	
Nc	50	80	90	110	
NuA	50	50	70	80	
NuB	50	50	70	80	
Om	50	70	90	100	
Os	160	250	340	400	
Pa	60	90	110	130	
Pf	60	80	110	130	
Pr	50	70	90	110	
ReA	170	280	380	400	
ReB	170	280	380	400	
SdB	180	290	380	400	
SIB	150	230	310	380	
SuA	60	80	110	130	
SuB	60	80	110	130	
SyB2	130	210	270	340	
SzA	160	270	360	400	

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
Pope County, Minnesota Table date: March 8, 2012

	50	70	90	110
Ta	50	70	90	110
To	50	70	90	100
Va	50	50	60	70
Wa	120	240	340	400
WbA	50	60	70	90
WbB	50	60	70	90
WdB2	50	50	70	80
We	50	60	80	90
Wn	50	60	80	90

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.